

MiniVol[®] TAS

Tactical Air Sampler

AIR METRICS



The MiniVol Tactical Air Sampler (TAS) is based on the original MiniVol air sampler developed jointly by AirMetrics and the United States Environmental Protection Agency (EPA) in 1990. Implementing patented low-flow technology, the TAS delivers precise and accurate results in a lightweight compact device.

The MiniVol TAS is a versatile platform that is attractive to end-users worldwide. With a broad range of customers, both domestic and international, the reliable and proven MiniVol sampling system has made a place for itself in the global air quality industry.

Improving upon the best in portable air samplers, the TAS leads the way for the next generation of innovative air sampling equipment.

**The next generation
of innovative air sampling
equipment**

AIR METRICS

2095 Garden Ave., Suite 102 ■ Eugene, Oregon 97403 ■ (541) 683-5420
(541) 683-1047 (FAX) ■ www.airmetrics.com

FEATURES

MiniVol[®] TAS

Tactical Air Sampler

LOW MAINTENANCE

All sampler components were designed for maximum durability and minimal maintenance. Even the routine cleaning of the size selective inlets has been simplified with the design of the Easy Maintenance Target (EMT).

LIGHTWEIGHT & PORTABLE

The compact sampler design weighs less than 10LBS when fully configured. The sampler and accessories are easily stored in an all-in-one transport case.

WELL EQUIPPED

Duplicates of major sampler components are included to simplify field work. The extra battery, filter holder and size selective inlet can be serviced while the duplicates are in use. The standard PM-10 sampler includes:

- | | |
|------------------------------|----------------------------|
| 1 Pump Module | 2 PM-10 Impactors |
| 2 Louvered Inlets | 2 Filter Holder Assemblies |
| 2 Li-Ion Battery Packs | |
| 1 Battery Charger | |
| 1 Universal Mounting Bracket | |

ALL-WEATHER CASE

Durable polypropylene copolymer case features a double-throw latch system for secure closing and easy opening.

EZ-INSERT BATTERY

The high-density Li-Ion pack weighs under two pounds and can be fully charged in less than five hours. The battery slides securely into the front panel for 60+ hours of sampling.

TECHNICAL SPECIFICATIONS

Active flow Control

Flow range: 0-10 LPM

Nominal flow: 5LPM

Sampler Dimensions: 10" x 12" x 7"

Sampler Weight: 9.8LBS (fully configured)

Transport Case: 19.75" x 12" x 18"

Shipping Weight: 37LBS

Li-Ion Battery 14.8V / 118 Watt Hours

Battery Charger: Input 100-240VAC, 47-63Hz
Output: 18VDC, 2A

MULTIPLE MOUNTING OPTIONS

A universal mounting bracket allows for attachment to vertical or horizontal surfaces, the fold-up lightweight tripod allows for free standing operation.

POWER OPTIONS

The TAS functions via AC/DC or solar power for urban or remote location sampling.

HIGH EFFICIENCY PUMP

Airmetrics introduces a double diaphragm pump designed specifically for the TAS. The pump incorporates Airmetrics' unique "laminar flow valve technology" and features a precision Swiss ball bearing motor with precious metal commutation, designed for a service life in excess of 10,000 hours.

SAMPLING MEDIA

The TAS utilizes standard US EPA FRM 47mm cassettes. A wide variety of filter media is available for specific sampling applications.



AIRMETRICS

2095 Garden Ave, Suite 102 ■ Eugene, OR 97403 ■ (541) 683-5420 ■ (541) 683-1047 (FAX)