

Redpost Printer/Charger, RPC-50

General information

The Haffmans-Redpost Printer/Charger is a computer interface and charger to be used together with the Haffmans-Redpost PU Monitor. The RPC-50 is suited to operate all RPU-120⁺, RPU-351, RPU-352 and RPU-353 PU-Monitors. By the use of the Red-Link software, the data stored in the PU-Monitor are downloaded to your PC where they can be printed and/or stored.

Principle of operation

After the pasteurising monitor has travelled through the tunnel pasteuriser, the measurement stops and the number of PUs is displayed on the pasteurising monitor. When the pasteurising monitor is connected to the Printer/Charger, it will detect the monitor and start charging. The RPC 50 downloads the results stored in the pasteurising monitor and passes the data on to your PC.

The Red-Link software processes the data and displays it in tabular and graphical format, which can be printed on any printer that is connected to the PC. These results can also be stored.



Beverage Quality Control



process



beer



soft drinks



Technical information

Features

PC interface

Advantages

Suited for Haffmans-Redpost PU-Monitors type RPU-120*, RPU 351, RPU-352 and RPU-353
No operation

Benefits

Archiving for ISO 9000
No maintenance

Scope of supply

RPC 50
Mains cable with Euro plug* (CEE-7/VII, IEC-83/C4)
Monitor connecting cable
Printer cable
Red-Link software
Operating instructions

*Mains cable can also be delivered on request with the following plugs:

American plug (NEMA 5-15P, IEC-83/A5-15)
British plug (BS 1363A, IEC-83/B2)
Swiss plug (SEV Type 12)
Australian plug (ASC 112)

Technical data

Voltage: 100-240 V AC/ 50-60 Hz
Interfaces: RS-232
PU-Monitor
Charging time: 4 hours to fully charge the PU-Monitor
Dimensions in mm: 190 x 130 x 105 (L x W x H)
Weight: 530 g

Haffmans B.V. reserves the right to make changes in the technical specifications at any time.



Haffmans B.V.

P.O. Box 3150 NL-5902 RD Venlo, The Netherlands

T: (+31) (0)77 323 23 00 F: (+31) (0)77 323 23 23

E: customersupport@haffmans.nl I: www.haffmans.nl



ISO 9001 : 2000 Accredited by RvA



NORIT *The Purification Company*

RPC-50