

# membrane dryer



The oil-less JUN-AIR compressors are available with membrane dryers. The dryer is designed for continuous operation, ensuring a constant supply of clean and dry air.

The membrane dryer removes water vapour after the receiver and the dew point will become lower than the ambient temperature. This will ensure no free moisture.

The range of membrane dryers includes three sizes. JUN-AIR compressors designated with a "D" followed by a letter in the model description (e.g. OF302-25BDA) is fitted with a membrane dryer. The letter after »D« refers to the size of the dryer.



Dryer type	Compressor model	Purge loss	Pressure dew point reduction @ 7 barg	Part no.
DA	OF301	32%	25°C	4082300
DA	OF302	17%	17°C	4082300
DB	2xOF302	20%	17°C	4082305
DA	1000	15%	9°C	4082300
DB	1000	37%	33°C	4082305
DB	2000	18%	15°C	4082305
DC	2000	36%	33°C	4082310
DC	4000	18%	14°C	4082310

**JUN-AIR**®

E-mail: [info@jun-air.dk](mailto:info@jun-air.dk)  
 Internet: [www.jun-air.com](http://www.jun-air.com)